

## ASSEMBLE YOUR DEEP RAISED-BED FRAME

### STEP 1: CUT LIST - MAIN FRAMES

- 4 2x10x96" PT pine (2x10x8')
- 4 2x10x45" PT pine
- 8 1x4x18" PT pine

### STEP 2: ASSEMBLE FRAMES, LEVELS 1 & 2

- A. Drill 4 3/16" pilot holes in the end of the 96" 2x10



- B. Attach 96" /10 to 45" 2x10 with 4 3" screw  
C. Repeat and join the two 'L's together for the first level.



- D. Repeat process to make the second level. You now have two 9" boxes ready to be stacked.

